

Do wrong side first

Lay fabric on ironing board right side down (horizontally). Mark the right end with a pin or in some other way to indicate it is end A.

From end A Fold up 1/4" - press (line 1)
 Fold up a second time 3/4" - press (line 2)
 Fold up a third time 7" - press (line 3)

From end B: Fold up 1/4" - press (line 1)
 Fold up a second time 3/4" - press (line 2)

Now turn your fabric over.

From end A: Fold up 7" - press (line 3)

From end B: Fold up and match the short sides.

Press heavily and then allow fabric to cool so that the fold lines can easily be seen.

The vertical lines on this card are 6 1/2" apart to help you keep your fabric straight.

③

②

①